




VIDEO-CD/LDP/CD PLAYER

DV5620KV/DV4620V

SERVICE *Manual*

This service manual is based on Model DV7620KV/DV7622KV(CODE NO : AH68-20127A).
This service manual contains change notes differing from the Model DV7620KV/7622KV.
For the change notes, refer to the "contents".

VIDEO-CD/LDP/CD PLAYER




CONTENTS

1. Wiring Diagram
2. Block Diagrams
3. PCB Diagrams
4. Schematic Diagrams
5. Exploded Views and Parts List
6. Troubleshooting
7. Electric parts List


4-1.Front (DV5620KV)




4-2. Main (1/4 Servo Section, DV5620KV /DV4620V)




4-3. Main (2/4 LD Video Section, DV5620KV /DV4620V)




4-4. Main (3/4 Audio Section, DV5620KV /DV4620V)




4-5. Main (4/4 Syscon Section, DV5620KV/DV4620V)



4-6. Main (NTSC / PAL Section)



4-7. Video-CD (DV5620KV /DV4620V)



4-8. Power (DV5620KV/DV4620V)

